

Index of Service Instructions

Revision: 3/03/06

No	Date	Subject	Applicability
2	5 Oct 1962	Installation and maintenance of 7-30 spring & tube assy	All Brantly B-2 helicopters
3	27 Apr 1965	Air filters	All Brantly B-2 helicopters
4	22 Jan 1963	Modification of engine cooling box assy P/N B2-196-2.	All left handed cooling box assy. P/n B2-196-2 when installed on the VO-360 B1A oil squirt engine.
5	26 Sept. 1993	Swash-plate drag link adjustment.	All Brantly helicopters
6	10 Jan 1964	Engine starting procedure	All B-2 series helicopters
7	18 Feb. 1964	Lubrication of tail rotor pitch change rod end bearings	Brantly helicopters equipped with p/n 325-20 tail rotor pitch change rod end bearings
8	19 Aug 1964	Alternate inboard blade thrust bearings	Brantly B-2, B-2A, and B-2B model helicopters prior to serial no. 418. Helicopters serial no. 418 and subsequent have the new type thrust bearings installed during production.
9	23 Apr 1965	Alternate replacement bearings	Brantly B-2, B-2A and B-2B model helicopters
10	14 Sept 2005	Upper Tail Rotor Gearbox Assembly, Installation, Maintenance	Brantly B-2, B-2A and B-2B model helicopters
15	5 Dec. 2005	Main Rotor Tracking, and Balancing	Brantly B-2, B-2A and B-2B model helicopters
16	3 Mar 2006	Lag Damper Inspection & Installation	Brantly B-2, B-2A and B-2B model helicopters